


# TECHNICAL INFORMATION

## Protocol Options



## Protocol Combinations for 5 and 15 Series - By Output

INPUT		OUTPUT		MODELS
Ethernet	TCP Server	Ethernet	TCP Client	All Models
Ethernet	UDP Server			
Ethernet	TLS over TCP Server			
Ethernet	TCP Server	Ethernet	UDP Client	
Ethernet	UDP Server			
Ethernet	TLS over TCP Server			
Ethernet	TLS over TCP Server	Ethernet	TLS over TCP Client	
Ethernet	SFTP Server	Ethernet	SFTP Client	
Ethernet	FTP/FTPS Server	Ethernet	FTP/FTPS Client	
Ethernet	Modbus TCP Master/Client	Ethernet	Modbus TCP Slave/Server	
RS485	Modbus RTU Master/Client			
Ethernet	Modbus TCP Master/Client	Ethernet	MQTT Client (Fend Cloud-AWS) TCP Client (JSON)	
RS485	Modbus RTU Master/Client			
Ethernet	BACnet IP (Listen)			
RS485	BACnet MSTP (Listen)			
Ethernet	LON IP (Listen)	Cellular	MQTT Client (Fend Cloud-AWS)	CE5/CE15 Only
Ethernet	Modbus TCP Master/Client			
RS485	Modbus RTU Master/Client			
Ethernet	BACnet IP (Listen)	Cellular	MQTT Client (Fend Cloud-AWS)	
RS485	BACnet MSTP (Listen)			
Ethernet	LON IP (Listen)			

# TECHNICAL INFORMATION

## Protocol Options

### Protocol Combinations for 5 and 15 Series - By Input

INPUT		OUTPUT		MODELS
Ethernet	TCP Server	Ethernet	TCP Client	All Models
			UDP Client	
Ethernet	UDP Server	Ethernet	TCP Client UDP Client	All Models
Ethernet	TLS over TCP Server	Ethernet	TLS over TCP Client	All Models
		Ethernet	TCP Client	
		Ethernet	UDP Client	
Ethernet	SFTP Server	Ethernet	SFTP Client	All Models
Ethernet	FTP/FTPS Server	Ethernet	FTP/FTPS Client	All Models
Ethernet	Modbus TCP Master/Client	Ethernet	Modbus TCP Slave/Server	All Models
		RS485	Modbus RTU Slave/Server	SE5/SE15 Only
		Ethernet	MQTT Client (Fend Cloud-AWS) TCP Client (JSON)	All Models
		Cellular	MQTT Client (Fend Cloud-AWS)	CE5/CE15 Only
RS485	Modbus RTU Master/Client	Ethernet	Modbus TCP Slave/Server	All Models
		RS485	Modbus RTU Slave/Server	SE5/SE15 Only
		Ethernet	MQTT Client (Fend Cloud-AWS) TCP Client (JSON)	All Models
		Cellular	MQTT Client (Fend Cloud-AWS)	CE5/CE15 Only
Ethernet	BACnet IP (Listen)	Ethernet	MQTT Client (Fend Cloud-AWS) TCP Client (JSON)	All Models
		Cellular	MQTT Client (Fend Cloud-AWS)	CE5/CE15 Only
RS485	BACnet MSTP (Listen)	Ethernet	MQTT Client (Fend Cloud-AWS) TCP Client (JSON)	All Models
		Cellular	MQTT Client (Fend Cloud-AWS)	CE5/CE15 Only
Ethernet	LON IP (Listen)	Ethernet	MQTT Client (Fend Cloud-AWS) TCP Client (JSON)	All Models
		Cellular	MQTT Client (Fend Cloud-AWS)	CE5/CE15 Only